

How to attach AeroPod to your bike

May 2022



AeroPod must be very stiffly attached to your bike, so that it cannot rotate in the mount, and where it is mounted does not flex.

Handlebar Mount

AeroPod ships with a round, machined aluminum, 31.8mm handlebar mount. Follow the illustrated instructions for attaching AP with this mount.

Combo Handlebar mount

If you purchased the optional Combo Handlebar mount, attach it following the same instructions for the Handlebar Mount. Make sure you attach the mount to your handlebars so that, when AeroPod is attached to the mount, AeroPod is reasonably level above the ground (+/- 20 degrees)

Aero-shaped bars

Some cyclists will use AeroPod with Aero-shaped handlebars, or handlebars with aero extensions.

AeroPod must be stiffly attached to the bike, no matter what kind of handlebars you are using.

Mounting alternatives that work

Here are some images of different handlebar setups that work (i.e. AeroPod is VERY stiffly attached to the bike):

1. Combo Garmin/Wahoo/AeroPod mount, for 31.8 mm round handlebars



2. Combo Garmin/Wahoo/AeroPod mount for attachment under aero bars



3. GoPro Grab Bag Helmet mount; double-sticky tape attaches mount to the underside of aero bars



And, here is a mount system that DOES NOT WORK (because the aero bars flex)



Questions about your mount? Please email us at technicalsupport@velocomp.com